



INSTALLATION INSTRUCTIONS

2017+ CAN-AM® MAVERICK X3® DOME LIGHT MOUNT



PRODUCT INCLUDES:
(1) Dome Light Mount Bracket #41636

* LIGHTS SOLD SEPARATELY

***THIS MOUNT FITS THE FOLLOWING LIGHTS:
(1) A-Series®**

IMPORTANT

THANK YOU FOR PURCHASING RIGID PRODUCTS FOR YOUR VEHICLE.
Please read through all of these Instructions and tips before proceeding with the installation. We do our best to provide a simple installation process for all applications however a professional installation is always recommended.

**Always disconnect any power sources connected to your vehicle
before servicing fuses or electrical systems.**

STEP 1

Install the A-Series light onto the RIGID dome light bracket using the provided hardware.

STEP 2

Remove the factory rear view mirror bolt and then install the new RIGID bracket. Re-install the factory bolt and tighten.

See Figures 2, 2.1

FIGURE 2



FIGURE 2.1



STEP 3

Once the mirror bolt is tight, aim light downward and you are finished with the installation.

See Figure 3

FIGURE 3



Wiring: Wire your lights according to the instructions included with the light. Take care to avoid any heat sources and sharp or abrasive surfaces.

**Your installation is now complete.
Welcome to the Rigid Nation!**

WARRANTY INFORMATION

For warranty information, visit www.rigidindustries.com/about/warranty
779 N Colorado St, Gilbert, AZ 85233 • 855-760-5337
www.rigidindustries.com

A-Series, RIGID and Rigid Industries are registered and/or common law marks owned by JST Performance, LLC, a Delaware limited liability company d/b/a Rigid Industries.

11-12459-A