

## **Can-Am Axle**

Thank you for choosing SUPERATV's brand axle. The following instructions will ensure a fast and accurate install of your new axle.

Your Can Am has a 2 phase spline design inside your differential. The following steps will guide you through the install.

- 1. Install your axle into the differential pushing the splines in until you feel it "click".
- 2. After you feel the "click" simply rotate your axle in either direction while still pushing in. You should feel a second "click" Sometimes you will even have to rotate the opposing side axle to get the new axle to seat correctly.
- 3. The newly installed axle will have a dust shield that should fit firmly against differential housing.
- 4. Give your new axle a quick tug to ensure proper seating of axle clip. If the axle stays in then the process was successful. If it comes out with relative ease then repeat steps 1-4 until achieving a proper fit.

