



SSV WORKS, 201 N. Rice Ave Unit A, Oxnard, CA 93030  
www.SSVworks.com | Phone: 818-991-1778 | Fax: 866-293-6751

# CM-FKP65

## Commander and Maverick 6.5" Speaker Front Kick Panels

### WARRANTY INFORMATION:

All SSV Works enclosures are covered by a limited lifetime warranty against defects in material or workmanship. All SSV Works Electronics are covered by a limited 1 year warranty against defects in material or workmanship. All SSV Works Speakers are covered by a limited 1 year warranty against defects in material or workmanship. Labor for replacement of defective components is not covered. Contact SSV Works for further warranty information.



Please read and understand these instructions completely before installation to avoid possible injury, or damage to the accessory or vehicle.

### TOOLS NEEDED FOR INSTALLATION

- Wire Crimpers
- Wire Strippers
- 5/32 Allen Wrench
- 7/16" Open End Wrench
- Drill with 1/8" and 1/4" Drill bit
- #2 Phillips Screwdriver
- T-30 Torx wrench
- Scribe or Marker

### PARTS LIST

- |                                    |                     |
|------------------------------------|---------------------|
| 1. CM2-FKP65-U Enclosures (1 pair) | 3. 1/4" Washers x 6 |
| 2. 1/4" x 20 Allen Bolt x 6        | 4. 1/4" Nut x 6     |

### PARTS LIST IMAGES



1. CM2-FKP65-U Enclosures  
(1 pair)



2. 1/4 x 20 Allen Bolt x 6



3. 1/4" Washers x 6



4. 1/4" Nut x 6

### INSTALLATION NOTES

The use of a thread locker is recommended on all screws to prevent loosening due to vibration. Sealing all wiring holes with a silicone sealer will prevent moisture from entering the enclosure. The glove box does not need to be removed for Kick panel installation; ours was removed for photo purposes only.



A. Align the kick panel above the foot rest and flush against the firewall and outside of the vehicle (under the glove box on the passenger side & mid way up the firewall on the driver side); the enclosure is in the correct mounting location when it sits flush on all sides. Using a scribe mark the 3 mounting holes.



B. After marking the holes, drill the mounting holes with the 1/4" drill.



C. Drill a 1/4" hole in the enclosure for the speaker wire to run out of, we recommend the flat side toward the top of the enclosure.



D. Mount the enclosure into the vehicle using the supplied hardware, putting the nut on the inside of the enclosure is recommended. Removing the 4 - T-30 Torx along the side of the vehicle will make this step easier.



E. Place the speaker into the enclosure and mark the 4 mounting holes with a scribe or marker, Pre-drill the marked mounting locations using a 1/8" drill bit.




F. Connect and install the speaker into the enclosure using the #2 Phillips screwdriver (be sure to connect the “+” speaker wire to the “+” terminal on the speaker and the “-” speaker wire to the “-” terminal on the speaker), repeat for other side.



G. Route the speaker wire away from any moving parts and any sharp metal, then connect to the amplifier.

## WIRING INSTRUCTIONS



For proper sound, ensure the speaker polarity is correct connect the “+” to the “+” and the “-” to the “-” from the speaker wire to the amplifier. If using with an SSV Works complete system refer to the amplifier wiring instructions for more detailed wiring information.